

MERC
4.5 • 7.5
9.8

**OPERATION AND MAINTENANCE
MANUAL**

GENERAL INFORMATION

IMPORTANT OWNER IDENTIFICATION and REGISTRATION INFORMATION

It is essential that your selling dealer fills out the Motor Registration Card completely and mails it to the Retail Distributor immediately upon sale of the new product. It identifies name and address of the original purchaser, product model and serial number, date of sale, type of use and selling dealer's code, his name and address. The dealer also certifies that you are the original purchaser and user of the product.

See Warranty Policy and information on outside back cover of this book.

IMPORTANT: Read this book carefully and thoroughly, particularly SAFETY WARNING,

CAUTION and IMPORTANT information in bold type, such as this paragraph.

DIRECTIONAL REFERENCES

All directional references are given as they appear when viewing boat from stern, looking toward bow.

SERIAL NUMBER

The serial number is stamped into the serial number plate on the swivel bracket. This number is the manufacturer's key to numerous engineering details which apply to your motor. When ordering parts, accessories and tools, or when corresponding with the dealer in regard to service matters, always specify model and serial number.

The design and construction contained herein were in effect at the time this guide was approved for printing. Mercury Marine, whose policy is one of continuous improvement, reserves the right to change models at any time, or to change construction or designs, without notice and without incurring obligation.

PERIODIC CHECKUP

After 20 hours, an inspection should be performed by an Authorized Outboard Dealer at local rates and paid for by the owner.

After the 20-hour check, your outboard should be taken to an Authorized Dealer every 100 hours of operation - or at least once each year - for lube change, tuneup, etc.

To find the Authorized Service facilities in your locality, or when traveling, refer to the classified or yellow pages in the local telephone directory under "Outboard Motors" or "Marine Engines."

This owner's publication includes operation and service instructions. If disassembly or replacement, particularly of internal parts, is required, the owner is advised to see an Authorized

Service Dealer and not to attempt the repair work himself.

SPECIFICATIONS


	Model 95...	Model 115	
Year	50 Range 2000's	50 Range 1200's	
Stroke	14.5 mm 1.31"	14.5 mm 1.31"	
Piston Displacement	180cc (11 Cu. In.)	90cc (5.5 Cu. In.)	
Recommended Spark Plug	Champion QL-77M	Champion QL-78V	
Spark Plug Gap	0.015"		
	Model 115	Model 150	Model 175
Crankshaft Diameter	46	50	50
Propeller Diameter	16	18	20
RPM Range	4500-5500		
Fuel Tank Capacity*			
Liters	11-1/11	11-1/4	11-1/4
Imperial Gals.	2-1/2	2-1/2	2-1/2
U.S. Gallons	3	3	3

* Additional capacity for oil included.

① Refer to the recommended oil capacity at the crankshaft for the appropriate model.

② Measure the propeller diameter with a vernier caliper.

① 2-Cyl. Merc 7.5E Shawn



1. Flywheel
2. Crank
3. Piston
4. Piston Pin
5. Piston Ring
6. Piston Ring Groove
7. Piston Ring Groove
8. Piston Ring Groove
9. Piston Ring Groove
10. Piston Ring Groove
11. Piston Ring Groove
12. Piston Ring Groove
13. Piston Ring Groove
14. Piston Ring Groove
15. Piston Ring Groove
16. Piston Ring Groove
17. Piston Ring Groove
18. Piston Ring Groove
19. Piston Ring Groove
20. Piston Ring Groove
21. Piston Ring Groove
22. Piston Ring Groove
23. Piston Ring Groove
24. Piston Ring Groove
25. Piston Ring Groove
26. Piston Ring Groove
27. Piston Ring Groove
28. Piston Ring Groove
29. Piston Ring Groove
30. Piston Ring Groove
31. Piston Ring Groove

MOTOR INSTALLATION

OUTBOARD MOTOR MOUNTING

SAFETY WARNING: Before operating motor, it is advisable to bolt the motor to the transom. During operation, clamp screws should be checked occasionally for tightness on the transom. Failure to bolt motor to transom may result in damage to boat, loss of motor and possible injury to occupants of boat.


Your motor is designed for a recommended transom height. To avoid damage to transom and to prevent motor from working loose during operation, it is important that clamp (thumb) screws are tightened securely and equally. Thumb screw grips should be in (or near) a horizontal plane to allow full tilt up and turn of motor. Failure to observe this thumb screw position could result in damage to steering parts.

TILT ANGLE ADJUSTMENT

Holes are provided in the clamp bracket to permit re-locate location of tilt lock pin for proper adjustment of tilt angle. Adjust tilt angle so that boat rides level (Figure 2)

2 How to Plane a Boat

- a **WRONG!** Bow Up
- b **WRONG!** Bow Down
- c **RIGHT!** Plane or Even keel



<https://www.boat-manuals.com/>

ELECTRICAL ACCESSORIES CONNECTIONS

Any accessories, such as horn, running lights, etc., should be installed with electrical connections attached directly to the battery terminals via the screws at the battery legs.

LIGHTING CIRCUIT (Merc 9.8-7.5)

Manual-starting Merc 9.8-7.5 engines are equipped with a lighting circuit which supplies 20 watt 12 regulated 12V power for lighting accessories and the installation of auxiliary lighting. A 16 gauge wire set is furnished for auxiliary light wiring.

PROPELLER RECOMMENDATIONS

PROPELLERS

For propeller recommendations applying to your particular boat, consult your dealer. Using an improper propeller can cause serious damage to your outboard motor.

SAFETY WARNING: When installing or removing propeller, place a block of wood between the anti-cavitation plate and propeller to prevent accidental motor starting and to protect the Rands from propeller blades while removing the propeller nut.

INSTALLING PROPELLER

1. To aid in future removal of the propeller, liberally coat the propeller shaft splines with one of the following Quicksilver products:
 - Special Lubricant 101
 - 2-4-C Multi-Lube
 - Perfect Seal
2. Slide collar and propeller onto shaft.
3. Place washer and nut (Figure 3) on end of propeller shaft and, with wood block still in place, tighten nut securely.

REMOVING PROPELLER

1. Place a flat block of wood between anti-cavitation plate and propeller.
2. Remove propeller shaft nut and washer. (Figure 3)
3. Slide propeller off shaft.

3 Propeller Removal and Installation



- a Propeller Nut
- b Splined Washer
- c Quicksilver Product
- d Collar
- e Propeller Shaft
- f Gear Housing

FUEL MIXTURE AND FUEL SYSTEM

INSTALLING FUEL TANK

1. Place fuel tank in position in bottom of boat. (Figure 4)
2. Connect fuel line to motor by inserting twist connector into receptacle in bottom cowl. (Figure 5) Arrange the fuel line so that it cannot become pinched, kinked, sharply bent or stretched during operation of the motor. Check with the motor in far left and right turn positions.

CAUTION: Use CARE when transporting fuel tanks, whether in a boat or car. DO NOT fill fuel tanks to maximum capacity. Cool gasoline expands considerably and builds up pressure in the fuel tank due to higher outside temperatures. This can cause fuel leakage and a potential fire hazard.

4 Remote Fuel Tank

a. Filler Cap
b. Twist Screw



5 Twist Connector



GASOLINE-OIL SELECTION

Use any gasoline that will satisfactorily operate an automobile engine, and Quicksilver Formula 50-D 2-Cycle Outboard Lubricant. If 50-D oil is not available, consult your Authorized Dealer for an acceptable oil.

CAUTION: The use of other than Formula 50-D Oil or an acceptable oil may cause piston scoring, bearing failure or both. DO NOT, under any circumstances, use multi-grade or other highly-detergent automobile oils or oils which contain metallic additives. Use of improper gasolines and/or oil can cause serious damage to **your** outboard motor.

Type Oil	Metric Measure	Imperial Measure	U.S. Measure
Formula 50-D	100 cc add to each 20 liters of gasoline	1 1/2 heaping spoons to each 20 liters of gasoline	1 1/2 U.S. teaspoons to each 20 U.S. gallons of gasoline
Other Acceptable Oil	Use standard manufacturer's recommendation for gasoline oil ratio		

CORRECT FUEL MIXING PROCEDURE

CAUTION: Observe fire prevention rules, particularly the matter of smoking. Mix **fuel** outdoors or at least in a well-ventilated location.

FUEL MIXTURE

Use a 50:1 gasoline-oil ratio as shown in the following chart.

Mix fuel directly in the remote tank. Measure accurately the required amounts of fuel and gasoline. Pour a small amount of gasoline into remote tank (Figure 6) and add small amount of oil about the same amount as gas. Mix thoroughly by shaking or stirring vigorously.

ously, then add balance of oil and gasoline and mix again. Cleanliness is of prime importance in mixing fuel, as even a very small particle of dirt can cause carburetion trouble.

IMPORTANT: Always use fresh gasoline. When standing, gasoline forms certain gum and varnish deposits and, when kept in a tank for a length of time, may give carburetor trouble and cause spark plug fouling.

IMPORTANCE OF CONSISTENT FUEL MIXTURES

Carburetor idle adjustment is sensitive to fuel mixture variations which result from use of different gasolines and oils or due to inaccurate measuring or mixing. This may necessitate frequent readjustment of the carburetor idle needle. Be consistent. Prepare each batch of fuel exactly the same as previous ones.

IMPORTANT: Using less than the recommended proportion of oil may result in very serious motor

damage from lack of sufficient **lubrication**. Using more than the recommended proportion of oil **will** cause spark plug fouling, erratic carburetion excessive smoking and faster-than-normal carbon accumulation.

BREAK-IN PROCEDURE

CAUTION: Follow break-in procedure **carefully**.

1

Operate a new motor at varied throttle settings for the first hour (one hour). **AVOID** both wide open throttle operation and prolonged idle in cold water areas during this period.

After the first hour (one hour) of operation, the motor is ready for normal operation and may be run at any speed. **DO NOT EXCEED** the full throttle RPM range listed in "Specifications", preceding.

OPERATION

NOTICE: Models **7.5/9.8** ONLY: If your **motor** will be operated primarily in cold water areas [normal water temperature **BELOW 50° F (10° C)**] **and/or** areas where extreme day-to-day temperature variations of **20° F to 40° F (-6° C to 5° C)** are common, we recommend installation of a thermostat (OPTIONAL ACCESSORY for **7.5/9.8** models) in the engine cooling system.

A thermostat controlled cooling system maintains a constant, higher engine operating temperature, thus providing smoother engine operation, particularly at slower operating speeds. See an Authorized Servicing Dealer for this accessory.

CO-PILOT ADJUSTMENT

The co-pilot provides friction control in the steering mechanism. The recommended adjustment is such that the motor will remain in a fixed course position without the

need of manual correction. It will not be enough to allow the motor to steer. Adjustments are made by means of hexagonal head screws in top of steering head of the motor. Tighten the screws to increase friction, loosen to decrease friction. Do not touch the screws using your steering.

6 Co-Pilot Adjustment - Merc 9.8-7.5-4.5




6 Co-Pilot Adjustment Screws
to Tighten Friction

SHIFTING GEARS

Gear shift lever is located on right side of upper. The gear shift positions are FORWARD (toward front), NEUTRAL (vertical), and REVERSE (toward rear).

7 Shift Lever and **Model 9.8E and 7.5E Electric Start Button**



- a Shift Lever
- b Electric Start Button

THROTTLE SETTINGS

Ring on twist grip throttle has three settings: "Full", "Start", and "Shift Range" (Wright). The seat of the twist grip has a friction device. To hold boat in the hole (stable) at a desired boat speed, the ring should be set the desired speed, select the throttle setting for controlling the twist grip, turn the "Throt Set" ring clockwise to clear the drag, turn the "Throt Set" ring clockwise again FOR FORWARD, NEUTRAL THROT or REVERSE. To set through the "Throt Set" has been set to a hole, the twist grip will not engage until the hole is closed. If the twist grip is set to a hole, the "Throt Set"

FOR EMERGENCY STOP: depress "stop button" of bottom bowl (Figure 12)

If remote controls are used, apply throttle by the first degree of rotation of handle to start. If forward and reverse shifts the motor, the remainder of the system handle movement advances the throttle forward or reverse.

8 Twist Grip Throttle



05614


- a Ring
- b Throttle Set

TILT STOP LEVER

Motor can be locked in tilt position by pulling tilt stop lever (figure 9) with motor fully tilted.

IMPORTANT: Do not use tilt stop lever while trailering. Tilt motor and place a block of wood between clamp and swivel bracket.

9 Tilt Stop



- a Tilt Stop Lever
- b Reverse Lock Lever
- c Tilt Bracket
- d Swivel Bracket Fitting

STARTING PROCEDURE - MANUAL

- 1 Be sure fuel tank contains a sufficient amount of fuel mixture and that tank is properly secured in boat.

2. Turn fuel line 1/2 meter by inserting fist into motor area (especially in cold). To lock, twist 1/2 turn clockwise, as shown in figure 5.

3. Open air vent screw on fuel tank cap.

4. Prime fuel system by squeezing primer tube on fuel line (figure 6). When fully primed, fuel will feel "wet".

5. Shift into neutral.



138004

10 Priming Fuel System

11 Manual Choke (a) - Merc 9.8-7.5



SAFETY WARNING: Be sure that outboard is in "NEUTRAL" gear before attempting to start motor electrically or manually. If outboard starts while in gear, occupants may be thrown from boat.

6. Rotate twist grip throttle to "Start" position (figure 8).

7. If the engine is cold, pull out the choke knob (Figure 11) to place the choke in "On" position (on Merc 4.5, set the choke in closed position as indicated by arrow). Use of the choke is not necessary if engine is warm.
8. With shift lever in neutral position, pull starter handle.
9. After pulling starter handle once, place manual choke in "Off" position and again pull starter handle to start motor. Should a cold motor falter after starting, quickly move choke "On" and "Off" several times until motor runs steadily.

IMPORTANT: Starter is automatic rewind type. Proper operating technique will add many hours of life to starter cable and to starter internal mechanism. Grasp handle firmly and pull outward slowly until engagement of ratchet mechanism can be felt. Then continue outward pull with a full, vigorous stroke. Do not release handle at end of stroke and allow it to snap back. Retain grip on handle and allow cable to rewind slowly. Ratchet

release mechanism is designed so that starter cannot engage during **rewind**.

STARTING PROCEDURE - ELECTRIC

Merc 9.8 and 7.5

1. Connect battery leads to motor. Attach red lead to red post of battery and black lead to negative (-) post of battery. Use grease to prevent corrosion of terminals.
2. Be sure that fuel tank contains a sufficient amount of fuel mixture and that tank is properly secured in hull.
3. Connect fuel line to motor by twisting twist connector into receptacle on cowl. Lock by twisting 1/8-turn clockwise (Figure 5).
4. Operate vent screw on fuel tank cap (Figure 4).
5. Prime carburetor and fuel system by squeezing priming tube on fuel line. When fully primed, pressure will be felt. (Figure 10)

6. Shift into neutral.
7. Rotate twist grip throttle to "Start" position. (Figure 6)
8. Pull out the choke knob to place choke in "On" position.

IMPORTANT: Avoid use of choke during normal operation or if motor is warm.

9. With shift lever in neutral, press starter button to actuate the starter. (Figure 7) As soon as motor starts to run, release button and push choke knob in.

IMPORTANT: The starter motor is not designed for continuous operation, and serious damage may result if operated continuously for more than 30 seconds. Pause and allow the starter motor to cool off for 2 minutes.

10. If motor should falter, actuate manual choke.

OPERATION WITHOUT BATTERY (Electric Starting Models)

It is designed for emergency use only for starting and cannot be started and operated without a battery with a device needed to reinsert it. In the event of a battery not available period, however, we recommend that you contact your dealer with a yellow card alternately. In the case of a poor insulation or position leads to a complete disconnection between leads as a precaution against fire or damage. (Figure 10)

SAFETY WARNING: Battery leads MUST BE taped off (insulated) or positioned in a manner that prevents a completed circuit between the leads.

STOPPING PROCEDURE

If the motor is to remain installed on the boat, ready for immediate restart, stop by shifting into neutral and


depressing "Stop" button. (Figure 12) Hold "Stop" button down until motor has stopped rotating completely.

Close all vent screws on fuel tank cap.

12 Stopping (a) - Merc 9.8-7.5-4.5



13 Troll (a) - Merc 9.8-7.5-4.5



TILT-UP AND SHALLOW WATER TROLL LEVER OPERATION

Motor can be tilted up manually only when placed in "Forward" gear. (Figure 7)

Merc 9.8-7.5-4.5 motors can be placed in a shallow water "Troll" position and released from this position as follows:

<https://www.boat-manuals.com/>

1. Retard twist grip throttle to "Shift Range" (Figure 8) and shift into "Forward" (Figure 7).
2. Push shift lever in direction of "Troll." (Figure 13)
3. Tilt motor up manually to engage in shallow water "Troll" position.
4. To release from shallow water "Troll," retard throttle and shift to "Forward." Push shift lever to the side and down, then tilt motor manually to disengage from the "Troll" position.

SHALLOW WATER OPERATION

CAUTION: When shift lever is in "Neutral" or "**Reverse**" position, lower unit is locked in normal operating position. Shock load of impact could cause transom breakage, particularly **when** boat is backing up. Proceed cautiously when in reverse motion and be careful of underwater obstructions. Do not accelerate motor to high RPM.

<https://www.boat-manuals.com/>

OPERATION IN SALT WATER

Prior to operation in salt water, the lower unit should be thoroughly flushed with fresh water. The lower unit should be flushed with an approved corrosion and rust preventer.

DON'TS

1. Don't operate motor out-of-water or with the lower unit attachment, or water pump or water pump impeller damaged. Read "Flushing" instructions carefully, following.
2. Don't operate motor with shift lever protruded.
3. Don't try to shift gears up from twist grip throttle in "Shift Range" position.
4. Don't ease into engagement of transom quick start is recommended.
5. Do not tilt motor up with steering handle.

CAVITATION

Cavitation, which is evident when the motor speeds up but boat speed is reduced, is caused by one of the following:

1. Propeller operating too close to the surface.
2. Transom too high.
3. Tilt angle adjusted so that lower unit is too high.
4. Boat riding stern-high because of improper loading. (Figure 2)
5. Propeller fouled by weeds, rope, etc.
6. Damaged or broken propeller blades. Broken blade usually is indicated by excessive vibration.
7. Propeller safety clutch slipping due to damage.

WATER PUMP OPERATION

Normal water pump operation is indicated by a steady,

"tell-tale" stream of water issuing from a small hole at the rear of the bottom cow, while the motor is running. (Figure 1)

IMPORTANT: On 9.8 and 7.5 models, which are equipped with a thermostat (OPTIONAL ACCESSORY) in the cooling system (Figure 14), a "tell-tale" stream is NOT visible until the engine reaches normal operating temperatures, and the thermostat opens (5 to 45 seconds, depending upon engine RPM and water temperature).


If the "tell-tale" is intermittent or absent during operation (frequent visual check, STOP MOTOR IMMEDIATELY, and

- Check gear housing water intake for possible restriction (weeds, mud, etc.).
- Check "tell-tale" hose for possible restriction (use a piece of wire).
- Models 9.8 and 7.5 equipped with thermostat Check thermostat and/or thermostat housing for possible restriction and/or thermostat malfunction. (Figure 14)

If no restriction is evident, a malfunction has occurred at some other point within the cooling system, possibly the water pump itself.

Operation with a defective water pump or defunct fan in the cooling system will cause overheating and severe engine damage. Refer the motor to an Authorized Service facility.

**14 Rectifier/Alternator Leads -
Merc 9.8 and 7.5**



- a Rectifier
- b Yellow/Red Alternator Leads
- c Thermostat Housing (Optional)

SAFETY WARNING: If the motor will not be operated for a period of time, or it is to be removed from the boat, or it is to be tilted up, we recommend the following practice to prevent spillage from the carburetor throat and bowl and to prevent gum formations in the carburetor during storage:

1. Disconnect the fuel line.
2. Allow motor to run at idling speed until it stops of its own accord, indicating the carburetor has run dry.

REMOVING MOTOR FROM BOAT

When removing, keep motor in an upright position, resting on its skeg, until all water has drained from

the drive shaft housing. If the motor is placed on its side while water remains in the drive shaft housing, some water may enter the cylinders through the exhaust ports and cause an oil leak.

ADJUSTMENTS/MAINTENANCE


REMOVING TOP COWL

MERC 9.8-7.5: Remove top cowl by pushing cowl release lever on rear of bottom cowl and lifting cowl off (up and forward). (Figure 15)

MERC 4.5: Pull the two latch pin levers outward from side of bottom cowl (Figure 16) and lift top cowl off (up and forward).

Avoid operation of motor with cowling removed.

15 Removing Top Cowl - Merc 9.8-7.5



a Top Cowl
b Top Cowl Latch



CARBURETOR ADJUSTMENT

The carburetor has a fixed high speed jet, but an idle mixture adjustment is provided.

IDLE MIXTURE ADJUSTMENT (FIGURE 17)

Idle mixture cannot be adjusted effectively while in

“Neutral” or in forward full throttle. To do up’s mixture, set the “Forward” because of the risk of the carburetor adjusting.

The carburetor in set on the tank. The engine should started, run idle, and then set the carburetor. The needle valve is slightly open. The carburetor will start to idle. The needle valve is slightly open. The needle valve is slightly open. The needle valve is slightly open. This appears at the setting of the carburetor.

If the engine cannot start, allow the engine to run for several minutes before making further adjustments.

1. With motor running, at slow speed, adjust the carburetor. Turn the idle mixture adjusting screw counter-clockwise until motor starts to “back up” or runs uneasily, then to opposite mixture. (Figure 17)
2. Slowly turn the idle mixture adjusting screw for evenly and motor picks up speed.
3. Continue turning clockwise until too lean a mixture is obtained, and motor slows down and misfires.

17 Idle Adjustment



a Idle Adjustment
b Rich (Turn Left)
Lean (Turn Right)

1. Set adjustment screw halfway between rich and lean.

3. Do not adjust leaner than necessary to attain reasonably smooth idling. When final mixture is proper idle is set to just slight rich rather than too lean.

SERVICING FUEL TANK FILTER (FIGURE 18)


Detach the fuel line from the fuel tank and disconnect pickup tube. Use filter and fuel tank to disconnect. Clean fuel tank by pouring in clean fuel to gas filter to keep open.

SERVICING CARBURETOR FUEL FILTER/SCREEN

Carburetor fuel filter screen is more than after it to take care of all requirements under normal conditions. After all other checks, fuel filter screen obviously is the cause of the trouble, clean or replace the fuel filter screen as necessary. (Figure 19)

NOTE: More than fuel screen is located under the strainer cover on top of the carburetor.

18 Fuel Tank Filter



a Fuel Tank Filter

19 Carburetor Fuel Screen -
Merc 9.8-7.5



a Fuel Screen Cover
b Fuel Screen

LUBRICATION (FIGURE 20)

(Periodically every 25 hour,) lubricate the lower drive unit with Quicksilver Super-Duty Outboard Gear Lubricant as follows:

IMPORTANT: Do not use regular automotive grease in the lower drive unit.

14027



Figure 2: Lubricant Filler Tube
and Air Vent Screw



Figure 3: Housing Still Leaking

Because the lubricant is applied to the gears after the oil has been drained out, it is important to drain the oil.

IMPORTANT: Never apply lubricant to the lower unit without first removing lubricant vent screw, as the injected lubricant displaces air which must be allowed to escape so that the gear housing can be completely filled.

2. Insert lubricant tube into fill plug hole and inject lubricant until excess fluid starts to flow out of lubricant vent screw hole, remembering that the housing is filled.
3. If, place lubricant vent screw first, then fill plug, taking special care that the washer is in place under the head of plug so that water will not leak past the diaphragm into the gear housing.

Always use the correct lubricant. Use only Mobil Grease 220 or Grease 240. Do not use other greases. Use Mobil Grease 220 or Grease 240 for all applications. Do not use other greases. Do not use oil.

Figure 4: Grease Application & Wipe Off Excess

Apply a small amount of grease to the lower unit. Wipe off the excess. Do not lubricate the lower unit at top of lower unit.

2. Lubricate the tube filling the front of lower bracket. Figure 4.

LUBRICATION CHART

Fig.	Description	Type Lubricant	Fresh Water Frequency	Salt Water Frequency
20	Chest Housing	Quicksilver Super-Duty Grease	Once in 10 Days Once in 30 Days	Same as Fresh Water
19	Swivel Bracket and Swivel Pin	Quicksilver 2-4-C or Multi-Lube Lubricant	Every 30 Days	Every 30 Days
16	Tilt Table Fringe			
20	Throttle-Shift Linkage			
9	Reverse Lock Lever			
1	Thumb Switch	Quicksilver Anti-Friction Grease	Once in Season	Every 10 Days
3	Propeller Shaft	Quicksilver — Special Lubricant 101 — 2-4-C Multi-Lube — Perfect Seal		

NOTE: Lubricants, sealers, etc., can be obtained from your Authorized Service Dealer.

SERVICING SPARK PLUGS

SAFETY WARNING: Do **not touch** or disconnect any ignition system parts **while** engine is running or while battery cables of electric starting **models** are connected. Do not **remove spark plug connectors** and hold them in your hand to check for spark while **engine** is running, **as** high voltage is present. Never attempt to turn engine over by hand with propeller **or** flywheel.

1. Remove spark plug, clean end in-gross. If diameter of electrode is modest, replace with new spark plug.
2. Install spark plug. Start the threads one or two turns with fingers to avoid damage to cross-threading. After seating plug finger-tight on gasket, an additional 1/8 turn with a wrench will generally be sufficient to tighten. Do not over-tighten.

3. Connect the spark plug leads to their respective spark plug.

PREPARATION FOR STORAGE OR SHIPMENT

1. Operate motor in water to exhaust fuel and cooling system. Disconnect the fuel line from the motor and allow water to run at plug speed until it stops at its own accord, indicating that the carburetor has run dry.
2. Drain the Tank.
3. Lubricate lower drive unit.
4. Remove spark plugs.
5. Rotate crankshaft to a position where the No. 1 (cylinder) piston is at bottom dead center position. This can be determined by inserting a piece of wood into the spark plug hole. Apply a Mercury

approved formula seal into the spark plug hole of the No. 1 cylinder, allowing time for some of the oil to drain into the crankcase via the transfer port. Repeat this operation for the other cylinder, then install spark plugs and operate the starter vigorously to distribute oil around the inside of the crankcase and cylinders.

6. Clean the motor thoroughly, including all accessible powerhead parts. Install covers and apply a thin film of clean, fresh motor oil to all painted surfaces.
7. To aid in future removal of the propeller, liberally coat the propeller shaft splines with one of the following Quicksilver products:
 - Special Lubricant 101
 - 2-4-C Multi-Lube
 - Perfect Seal

IMPORTANT: When storing outboard motor for the winter, be sure that all water is drained from the gear housing (thru the propeller hub). Trapped water may freeze and expand, thus cracking the gear housing and/or water pump housing.

Check and refill lower unit, as explained, before storage to protect against possible water leakage

into gear housing which is caused by loose lubricant vent screw or loose fill plug. Be sure to replace gaskets under screws, replacing any damaged gaskets.

ATTENTION REQUIRED FOLLOWING OPERATION IN SALT WATER OR SILT

Even though the interior surfaces are treated to resist corrosion, there still is a possibility of a mechanical buildup of salt and silt deposits when no form of protective coating can penetrate and which can be removed only by occasional flushing with fresh water.

1. When your outboard is left out for long periods in salt water:
 - 1. Lubricate handle screws with Quicksilver Anti-Tear-Out Grease
2. To aid in future removal of the propeller, liberally coat the propeller shaft splines with one of the following Quit-itsilver products:
 - Special Lubricant 101
 - 2-4-C Multi-Lube
 - Perfect Seal

4. Intake powerhead can be sprayed with a coating of a Mercury approved rust preventive oil to protect the finish of all parts beneath the cowl. The exterior also can be sprayed or wiped *to* prevent salt corrosion from dulling the finish.

a. To flush motor:

- Remove the stop plug marked "FLUSH" and water from flushing tube. Plug is located beneath drive shaft trim cover on 9.8-7.5 HP models (Figure 21) and in right side of bottom cowl on 4.5 HP model (Figure 22).
- Connect flushing jets and attach garden hose comply with hose.
- Turn on water. Turn HOX 104 (UP/EV) the outboard while flushing. Water flow is strong enough that flushing can be done with water pressure provided from the water tap. HOX 104 USE hot water pressure.

21 Flush Plug - Merc 9.8-7.5



21 Flush Plug

22 "FLUSH" Plug - Merc 4.5



While and after flushing, keep motor in upright position, resting on skeg, until all water has drained from drive shaft housing to prevent water from entering the powerhead via drive shaft housing and exhaust ports.

By following the preceding simple preventive maintenance operations at regular intervals, longer life will be added to your motor when used in salt water.

ATTENTION REQUIRED FOLLOWING COMPLETE SUBMERSION

In an effort to deter serious internal engine damage and avert expensive engine repairs, a motor, that has been submerged, requires IMMEDIATE service upon recovery.

1. Wash entire motor with clean, fresh water to remove mud, silt, weeds, salt, etc.
2. Remove the spark plug and purge the engine and carburetor of as much water as possible ("crank" engine with spark plug holes facing downward).
3. If compressed air is available, "blow-dry" the engine internally and externally.

4. Pour a liberal amount of **FourStroke Engine Cleaner** or **FourStroke Formula 50-D Outboard Lubricant** into the engine via the carburetor and spark plug hole.
5. Manually "crank" engine to distribute the lubricant within the engine, then drain excess lubricant from engine.
6. Reinstall spark plug and high tension lead.

IMPORTANT: If it appears that the engine DID NOT take in any foreign material (mud, sand, weeds, etc), and "cranks" freely, the engine should be started. If there is evidence that foreign material had entered the engine, the engine should be disassembled and cleaned (take motor to an Authorized Dealer for service).

7. Start engine and operate at low RPM for a minimum of 5 minutes, then run engine at varied throttle settings for an additional 15-20 minutes. (Normal operation will continue the drying-out process, displacing remaining moisture and providing internal lubrication.)
8. If engine performance still indicates engine trouble, take motor to an Authorized Dealer for further service.

TROUBLESHOOTING

IMPORTANT: The following chart is intended as a guide to aid in finding and correcting minor outboard motor malfunctions, should they occur. Possible causes are listed in order of probability and, even though some **may** appear to be quite obvious, these same causes often are overlooked when a problem **occurs**. If a problem **cannot** be located and corrected with the aid of the guide, see your Authorized Dealer for further service. For **manual** start engines, disregard references to electric starting.

SAFETY WARNING: Before attempting **any** checks or repairs, battery cables on electric start model **MUST BE REMOVED** from battery to prevent possible personal injury or damage to equipment.

Trouble	Possible Cause	Remedy
Motor will not start	<ul style="list-style-type: none"> • Fuel tank empty • Fuel tap closed • Fuel filter clogged • Fuel system venting blocked • Fuel system obstructed • Fuel system contaminated • Fuel system dirty • Fuel system airlock • Fuel system leaks 	<ul style="list-style-type: none"> • Fuel tank not clean or full • Fuel tap not open • Fuel filter not clean • Fuel system vent not open • Fuel system not open • Fuel system not open • Fuel system not open • Fuel system not open • Fuel system not open • Fuel system not open
Motor will not start (continued)	<ul style="list-style-type: none"> • Ignition switch not in "ON" position • Ignition switch not working • Ignition switch not connected • Ignition switch not grounded • Ignition switch not secured • Ignition switch not locked • Ignition switch not released • Ignition switch not reset • Ignition switch not replaced • Ignition switch not repaired 	<ul style="list-style-type: none"> • Ignition switch not in "ON" position • Ignition switch not working • Ignition switch not connected • Ignition switch not grounded • Ignition switch not secured • Ignition switch not locked • Ignition switch not released • Ignition switch not reset • Ignition switch not replaced • Ignition switch not repaired
Motor will not start (continued)	<ul style="list-style-type: none"> • Ignition coil not working • Ignition coil not connected • Ignition coil not grounded • Ignition coil not secured • Ignition coil not locked • Ignition coil not released • Ignition coil not reset • Ignition coil not replaced • Ignition coil not repaired 	<ul style="list-style-type: none"> • Ignition coil not working • Ignition coil not connected • Ignition coil not grounded • Ignition coil not secured • Ignition coil not locked • Ignition coil not released • Ignition coil not reset • Ignition coil not replaced • Ignition coil not repaired
Motor will not start (continued)	<ul style="list-style-type: none"> • Ignition coil not working (continued) • Ignition coil not connected (continued) • Ignition coil not grounded (continued) • Ignition coil not secured (continued) • Ignition coil not locked (continued) • Ignition coil not released (continued) • Ignition coil not reset (continued) • Ignition coil not replaced (continued) • Ignition coil not repaired (continued) 	<ul style="list-style-type: none"> • Ignition coil not working (continued) • Ignition coil not connected (continued) • Ignition coil not grounded (continued) • Ignition coil not secured (continued) • Ignition coil not locked (continued) • Ignition coil not released (continued) • Ignition coil not reset (continued) • Ignition coil not replaced (continued) • Ignition coil not repaired (continued)

Trouble	Possible Cause	Remedy
A. Engine will not start	<ol style="list-style-type: none"> 7. Loose or corroded battery connections 8. Stale or contaminated fuel 9. Improper fuel-oil ratio 10. Dirty, fouled or wrong type spark plugs 11. Poor connections or damaged ignition wiring 	<ol style="list-style-type: none"> 7. Reconnect and clean battery connections 8. Fill tank with clean fresh fuel 9. Mix correct fuel-oil ratio and use correct oil 10. See "Servicing Spark Plugs" procedure in manual 11. Check connections and electrical leads for continuity. Repair shorted or broken wires
B. Poor idling or engine misses while idling	<ol style="list-style-type: none"> 1. Fouled spark plugs 2. Fuel-air ratio adjustment 3. Stale or contaminated fuel 4. Throttle linkage not closing completely 5. Defective ignition component 6. Reed valve open or broken 	<ol style="list-style-type: none"> 1. See "Servicing Spark Plugs" procedure in manual 2. The screw on the carburetor should be turned in or out 2. Fill tank with clean fresh fuel 4. See "Adjusting Servicing Linkage" procedure in manual 5. See "Adjusting Servicing Linkage" procedure in manual 6. See "Adjusting Servicing Linkage" procedure in manual
C. Engine stalls at high speed	<ol style="list-style-type: none"> 1. Fouled or wrong type spark plugs 2. Stale or contaminated fuel 3. Wrong fuel and oil mixture 	<ol style="list-style-type: none"> 1. See "Servicing Spark Plugs" procedure in manual 2. Fill tank with clean fresh fuel 3. Mix correct fuel-oil ratio and use correct oil

<p>4. Engine runs at high speed but won't stop.</p>	<p>1. Fuel valve closed or fuel pump not working.</p> <p>2. Ignition coil not working.</p> <p>3. Ignition spark plug not working.</p> <p>4. Engine overheat.</p>	<p>1. Check engine for proper operation and tighten all loose connections. Repair as needed.</p> <p>2. See "Ignition", preceding in manual.</p> <p>3. See "Carburetor", preceding in manual.</p> <p>4. See "Fuel System", preceding in manual.</p> <p>5. See "Cooling System", preceding in manual.</p> <p>6. See "Anti-Siphon System", Dealer for proper synchronization.</p> <p>7. See "Governor", preceding in manual following in chart.</p>
<p>10. Starts well but won't hold charge to start motor.</p>	<p>1. Corroded or loose battery terminals.</p> <p>2. Low electrolyte level.</p> <p>3. Worn out or inefficient battery.</p> <p>4. Excessive use of electrical accessories.</p> <p>5. Defective rectifier.</p> <p>6. Defective alternator.</p>	<p>1. Clean and tighten battery terminals.</p> <p>2. Fill battery to recommended level.</p> <p>3. Replace battery with one of recommended capacity.</p> <p>4. Use battery of recommended capacity.</p> <p>5. See "Electrical System", Dealer for repair.</p> <p>6. See "Anti-Siphon System", Dealer for repair.</p>
<p>11. Motor speed faster than normal.</p>	<p>1. Transom too high.</p> <p>2. Boat improperly loaded.</p> <p>3. Tilt angle not correctly adjusted.</p> <p>4. Propeller of wrong pitch or diameter.</p> <p>5. Propeller damaged.</p>	<p>1. Have a qualified boatyard technician check transom.</p> <p>2. Distribute load properly to maintain level plane.</p> <p>3. Verify the motor is installed on the correct position.</p> <p>4. If still over speed properly operate the motor at recommended RPM range.</p> <p>5. Have a qualified boatyard technician check propeller.</p>

Trouble	Possible Cause	Remedy
<p>2. Motor speed slower than normal</p>	<ol style="list-style-type: none"> 1. Wounds or oil or other material tangled on propeller 2. Boat impinged on object 3. In clutch no case backlash 4. Excessive oil on propeller 5. Fuel impeded 6. Propeller damaged 7. Propeller or stern propeller bent 8. Governor valve control defective 9. Worn or open throttle linkage 10. Governor too slow adjustment 	<ol style="list-style-type: none"> 1. Remove debris from propeller 2. Do not re-engage motor until boat is clear 3. Adjust clutch backlash to normal (see adjustment) 4. Wipe excess oil from propeller 5. Use fuel system maintenance instructions 6. Check propeller for signs of damage 7. Check damaged propeller for cracks. If cracked, replace with a new one. Do not use a bent propeller. 8. Verify that the adjustment of the governor valve is correct 9. See "Service and Repair" section for instructions 10. See "Service and Repair" section for instructions
<p>3. Engine over-revving</p>	<ol style="list-style-type: none"> 1. Governor assembly bad 2. Fuel or air too fast at throttle valve needle, RPM 3. Governor too slow adjustment (too high rpm adjustment) 	<ol style="list-style-type: none"> 1. Check that the needle valve is set to "Water Pump Operation" position for normal 2. See "Fuel" section for correct fuel mixture. The needle valve is set to "Water Pump Operation" position for normal 3. See "Service and Repair" section for instructions

INDEX

	Page		Page
General Information	Cover	Tilt Stop Lever	11
Important Owner Identification and Registration Information	Cover	Starting Procedure - Manual	1
Directional References	Cover	Starting Procedure - Electric	3
Serial Number	Cover	Operation without Battery (Electric Starting Models)	3
Periodic Checkup	1	Stopping Procedure	14
Specifications	1	Tilt-Up and Shallow Water Trolly Lever Operation	15
Motor Installation	3	Shallow Water Operation	16
Outboard Motor Mounting	3	Operation in Salt Water	16
Tilt Angle Adjustment	3	Don'ts	16
Electrical Accessories Connections	4	Cavitation	17
Lighting Circuit	4	Water Pump Operation	17
Propeller Recommendations	4	Removing Motor from Boat	19
Propellers	4	Adjustments Maintenance	19
Installing Propeller	5	Ramming Top Cowl	19
Removing Propeller	5	Carburetor Adjustment	20
Fuel Mixture and Fuel System	6	Idle Mixture Adjustment	20
Installing Fuel Tank	6	Securing Fuel Tank Filter	21
Gasoline-Oil Selection	7	Servicing Carburetor Fuel Filter Screen	33
Fuel Mixture	7	Lubrication	22
Using Fuel Mixing Procedure	7	Servicing Spark Plugs	25
Importance of Correct Fuel Mixtures	8	Preparation for Storage or Shipment	25
Break-in Procedure	8	Attention Required following Operation in Salt Water or Silt	26
Operation	9	Attention Required following Operation	28
Cruiser Adjustment	9		
Shifting Gear	10		
Throttle Settings	10		

WARRANTY

- I. We warrant each new Mercury Outboard Motor and accessories attached thereto, (hereafter referred to as "Product", as manufactured by us, to be free from defects in material and workmanship.
- II. This warranty shall become effective only upon our receipt of a completed Product Registration Card, which shall identify the Product so registered by serial number. This warranty shall remain in effect for a period of one (1) year from date of purchase.
- III. Since this warranty applies to defects in material and workmanship, it does not apply to normal worn parts, adjustments, tuneups or to damage caused by: 1) Neglect, lack of maintenance, accident, abnormal operation or improper installation or service; 2) Use of an accessory or part not manufactured or sold by us; 3) Operation with fuels, oils or lubricants which are not suitable for use with the Product; 4) Participating in or preparing for racing or other competitive activity or operating with a racing type lower unit; or 5) Alteration or removal of parts.
- IV. Reasonable access must be provided to the Product for warranty service. This warranty will not apply to: 1) Hull and launch, towing and other charges; telephone or rental charges of any type, inconvenience, loss of time or income; or other consequential damages; or 2) Removal and/or replacement of boat partitions or material because of boat design for necessary access to the Product.
- V. Claim shall be made under this warranty by delivering the Product for inspection to a Mercury Marine dealer authorized to service the Purchaser's Product. If purchaser cannot deliver Product to such authorized dealer, he may give notice in writing to the area Mercury Marine distributor or Branch Manager or to the Company. Mercury Marine shall then arrange for the inspection and repair, provided such service is covered under this warranty. Purchaser shall pay for all related transportation charges and/or travel time. Further, if the service is not covered by this warranty, purchaser shall pay for all related labor and material. Any Product or parts shipped by purchaser for inspection or repair must be accompanied with transportation charges prepaid.
- The Owner's Registration MerCard is the only valid registration identification and must be presented at the time warranty service is required. Warranty claims will not be accepted without presentation of the MerCard.
- VI. Our obligation under this Warranty shall be limited to repairing a defective part or at our option replacing such part or parts as shall be necessary to remedy any malfunction resulting from defects in material or workmanship as covered by this Warranty. We reserve the right to change or improve the design of any Product without assuming any obligation to modify any Product previously manufactured.
- VII. This warranty is in lieu of all other warranties expressed or implied and may not be modified or extended by anyone, except that any modification or restriction contained herein which is prohibited by any law where the Product is sold and such qualification or restriction only is null and void. All other qualifications and restrictions of this warranty remain in full force and effect. There are no warranties which extend beyond the description on the face hereof.

MERCURY MARINE
DIVISION OF BRUNSWICK CORPORATION
FOND DU LAC, WISCONSIN 54935 U.S.A.

MARINE POWER - EUROPE
DIVISION OF BRUNSWICK S.A.
PETIT RECHAIN, BELGIUM

MERCURY MARINE LTD.
MISSISSAUGA, ONTARIO
CANADA

MERCURY MARINE PTY. LTD.
PO BOX 110 VICTORIA 3175
AUSTRALIA